

CAPITOL AREA FLYERS - STROCK AND KLINEDINST FIELD
STANDING FIELD RULES

1. Flying is limited to the following hours:

- The Strock Field
Monday through Friday – 9AM to Dusk
Saturdays – 9AM to 4PM
Sundays – ***Quiet Electric Aircraft Only*** Noon to Dusk
- The Klinedinst Field
9AM – 9PM Seven Days a week

Violation of these rules will result in immediate expulsion from CAF.

2. All transmitters must have a channel ID flag attached.
3. DO NOT turn on your transmitter until your AMA card is on the proper frequency hook on the frequency board.
4. All aircraft are allowed to fly including Helicopters. Fixed wing aircraft have the right of way.
5. Modern mufflers must be used for all fuel engines.
6. Aircraft must be restrained and point toward the flight line when starting.
7. DO NOT taxi out of, or into the Pit area.
8. Pilots must stand on the flight line and 20 feet apart when taxiing on the runway or flying.
9. Take offs and landings are to be at the center of the field.
10. No flying over or behind the flight line or beyond “Flying Boundary Markers”.
11. Keep low fly-bys beyond the center line of the runway.
12. YELL and warn of emergencies – Safety is first.
13. Landing aircraft have the right of way.
14. At the end of each flight turn off transmitters, collapse antenna and remove your AMA card from the frequency board. Be considerate.
15. No flying while grass is being cut or maintenance is being done.
16. NO ALCOHOLOC BEVERAGES are permitted on the site.
17. Guests and leashed animals must remain in the parking area.
18. No breaking in of engines is allowed at the field.
19. Maiden flights or repaired aircraft must only be flown when a minimum number of members are present.
20. No solo flights by new members are allowed until approved by a Club Instructor.
21. In the event a model should come down on neighboring property, that neighbor shall be contacted for permission to retrieve. We must not trespass on posted property.